

Serial – USB Adapter



Chapter 1

Hardware Installation

Plug the USB cable “A” type in to free USB Host port on computer.



Warnings

If your OS is Windows 98SE/ME, Windows has finished installing the software. Popup “To finish setting up your new hardware, you must restart your computer” wizard, please choose click “**NO**” to continue install the driver.

Chapter 2

Software Installation:


Supported OS

Microsoft Windows 2000, Windows XP, Windows ME, Windows 98SE are supported. Windows will automatically find the USB Serial Adapter, will prompt new hardware wizard. Please follow the software installation wizard step-by-step.


Step1 : Select “Install from a list or specific location (Advanced)”, choose click “**Next**”.




Step2 : Browser a CD driver specify a location, choose click “Next”.



Step3 : The system will automatically copy driver files.




Step4 : Install OK .Choose click **“Finish”**.



Step5 : The driver has been setup successfully. Please re-start the computer.


Step6 : Installation verification.





Open they the device manager and check they which Com haven installed the system!

Step7 : Choose the right **Com** connection in the program.



FOR COMPETITION USE ONLY

No warranty of any engine damage

We wish you great success with your new Igni-Power.

www.igni-power.com

©igni-power_LWO022006

